



Fireshield® WoodSafe™ - Exterior is a factory applied, fire rated solution used to impregnate timber to provide non-combustible, fire rated **BAL-29** and **Group 1** timber surfaces. No on site fire treatment is required.

**RECOMMENDED USE**

WoodSafe™-Exterior treated timbers are available in various wood species in any board profile, batten or sheet from all major timber Merchants nationwide or as finished timber supplied direct from Fireshield. WoodSafe™-Exterior treated timber can be used as:

- Exterior timber cladding. **BAL-29**
- Interior / Exterior wall & ceiling linings. **Group 1**

For internal dry areas consider using Fireshield® WoodSafe™-Interior.

**DURABILITY**

**Fire Protection Durability**

WoodSafe™-Exterior impregnated timbers have been weather tested to ASTM D 2898 Method B, and EN16755:2017 (INT-1, INT-2 and EXT and EXT-LR) for durability of reaction to fire performance and can be used in exterior environments without any protective applied stain or coating to achieve the fire classification.

**Timber Durability**

Timbers treated with WoodSafe™-Exterior will weather and age at the same rate as untreated timber, WoodSafe™ does not decrease the service life of the timber.

**MAINTENANCE**

The WoodSafe™-Exterior fire protection treatment is maintenance free and will last the lifetime of the timber when stored, installed and maintained in accordance with this document.

WoodSafe™-Exterior timbers will age and behave the same as untreated timbers of the same species.

- WoodSafe™-Exterior fire protection system has the ability to resist impact and abrasion.
- Excessive wear may damage the fire protection system and if so, require inspection and possible replacement.

Coatings applied to WoodSafe™-Exterior timbers will need to be maintained as per the coating manufacturers technical specifications.

**WARRANTY**

When stored, installed and maintained in accordance with this document the fire protection properties will remain for the service life span of the timber (subject to terms and conditions).

**TIMBER INFORMATION**

**EXTERIOR CLADDING - BAL-29**

Species	Minimum thickness	Fire Rating
Western Red Cedar	18mm	BAL-29

**EXTERIOR / INTERIOR LININGS - GROUP 1**

Species	Minimum thickness	Fire Rating
Western Red Cedar	18mm	Group 1-S

NOTE: Contact Fireshield prior to specifying to confirm timber availability, sizes and various face grades available.

**FIRE COMPLIANCE**

**BAL-29**

Tested and assessed according to AS 3959:2018, Appendix F, point F2 as a “Bushfire-resisting Timber”. The product is deemed to be acceptable to withstand exposure up to BAL-29. Compliance is achieved with NCC 2019 Clause G5.2.

**GROUP 1**

Tested and assessed according to AS 5637.1:2015 Part 1 and complies with NCC 2019 Specification C1.10 as a wall or ceiling lining system having a Group 1 with an average specific extinction area less than 250 m2/kg.

**COATINGS**

WoodSafe™-Exterior can be coated with Fireshield® approved stains, penetrating oils, paints, and polyurethanes. For the approved coatings list contact Fireshield®.

**Preparation**

- The surface to be coated must be completely clean and dry. Remove all dust, oil, grease, loose material or other contaminants.
- WoodSafe™-Exterior timbers can be lightly sanded prior to coating.
- Moisture content of the timber should not exceed 12-14% prior to coating.
- Follow coating Manufacturers technical data sheets for product application instructions.
- Always test coatings prior to full application on a small area first.
- Fireshield® approved coatings are tested for fire performance. Fireshield® is not responsible for any unexpected discolouration or inconsistencies in the visual appearance that may occur using an approved coating.

**SUSTAINABILITY**

All Fireshield WoodSafe™-Exterior timber products are certified by FSC and PEFC. Certification for each timber species will follow your order.



## TIMBER INSTALLATION

In addition to the relevant Australian standards, The National Construction Code and local Council guidelines, the timber must be installed in accordance with the guidelines below in conjunction with timber Merchant/Suppliers installation instructions:

- See the **WoodSafe™** Installation Supplement for the BAL-29 exterior system requirements and fixing details.
- Screw or nail fixings can be used.
- The head of the fixing should sit flush with the surface of the timber.
- Use the appropriate fixing type for the timber species specified by the timber Merchant/Supplier such as stainless steel nail and screw fixings that have excellent anti-corrosive characteristics and can sustain aggressive environmental conditions, for example stainless steel A4/AISI 316.
- For interior use, **WoodSafe™** treated timbers can be direct fixed to timber framing, existing linings and steel frame.
- Contact FireShield® prior to commencing any planing of the exposed timber surface if dimensional adjustments are required. Minor planing is acceptable.
- Drilling and creating perforations or holes is allowed, for example power box installation.
- The moisture content of **WoodSafe™-Exterior** timbers cannot be measured using standard probe techniques. Dry weight measurement calculations must be used.
- **WoodSafe™-Exterior** timbers do not decrease the life span of tools used in the installation process, however some tool surface discolouration can occur.
- Off cuts are safe to be collected and disposed of as per untreated timber regulations and guidelines.

## PRECAUTIONS

The following precautions must be taken:

- Read the **WoodSafe™-Exterior** Material Safety Data Sheet (MSDS) before installation and have a copy available on site at all times.
- Where conditions may require variation from the recommendations on this Technical Data Sheet you must contact FireShield® for advice prior to installation.
- Do not use or install in conditions outside the parameters stated in this document without the express written consent of FireShield®.
- All work involving the use of **WoodSafe™** product should be compliant with all relevant National Health, Work Safety & Environmental standards and regulations for timber products. For example wear dust mask, eye protection and gloves when handling and cutting timber.

## SUPPLIER : FIRESHIELD®

Australia  
13 North Concourse, Beaumaris,  
Victoria 3193, Australia  
ABN: 95 336 533 948  
Ph: 1800 092 097  
[www.fireshieldcoatings.com](http://www.fireshieldcoatings.com)



## COATINGS

**WoodSafe™-Exterior** can be coated with FireShield® approved stains, penetrating oils, paints, and polyurethanes. For the approved coatings list contact FireShield®.

### Preparation

- The surface to be coated must be completely clean and dry. Remove all dust, oil, grease, loose material or other contaminants.
- **WoodSafe™-Exterior** timbers can be lightly sanded prior to coating.
- Moisture content of the timber should not exceed 12-14% prior to coating.
- Follow coating Manufacturers technical data sheets for product application instructions.
- Always test coatings prior to full application on a small area first.
- FireShield® approved coatings are tested for fire performance. FireShield® is not responsible for any unexpected discolouration or inconsistencies in the visual appearance that may occur using an approved coating.

## STORAGE CONDITIONS

Moisture content when delivered is 15 - 20%.

Recommended storage conditions:

- Must be stored in a controlled environment equivalent to the final installation environment.
- The timber must be stored elevated (> 100mm) from ground or from a damp surface.
- Do not store timber packages tilted or on edge.
- Protect against dirt, contamination, direct sunlight, and rain during transport.
- Maintain straps until assembly is performed.

FireShield® will not be liable for any product failure if the conditions as to storage, handling, use and maintenance of **WoodSafe™-Exterior** timbers as outlined in this document are not complied with.

The **WoodSafe™-Exterior** treated timber must be allowed to acclimatise for a sufficient period of time to avoid cupping and shrinkage. As a guide, always allow **WoodSafe™-Exterior** timbers to acclimatize for at least 14 days in the same environment they will be installed in before installing permanently.



It is the user's responsibility to check that you have the latest technical datasheet available by visiting [fireshieldcoatings.com](http://fireshieldcoatings.com) or checking with your local FireShield Representative as the information contained in this technical data sheet is modified from time to time in line with our policy of continuous product development. The information in this data sheet is not intended to be exhaustive; any person using the product for any purpose other than that specifically recommended in this data sheet does so at their own risk. All advice given or statements made about the product (whether in this data sheet or otherwise) are correct to the best of our knowledge. Unless we specifically agree in writing to do so, we do not accept any liability at all for the performance of the product or for (subject to the maximum extent permitted by law) any loss or damage arising out of the use of the product. FireShield hereby disclaim any warranties or representations, express or implied, by operation of law or otherwise, including, without limitation, any implied warranty of merchantability or fitness for a particular purpose. You should request a copy of this document and review it carefully.